

# ECOUSTIC® TIMBRE PANEL TRIMMING GUIDELINES



unika vaev  
INSTYLE

# ecoustic® Timbre Trimming Guidelines

- The Timbre print does not extend to the edges of the panel
- An unprinted border occurs on all four sides
- The panels need to be trimmed before installation even when using edging profiles
- Make all measurements and cuts based on the printed area. Do not measure from the panel edge

Please adhere to the following guidelines for trimming:

- Measure within the printed area and using a straight edge cut horizontally and vertically to the size required
- Refer approximate print dimensions below
- Ensure all cuts capture the printed area
- The print is designed to simulate the natural variations of timber grain
- Panelling will occur when joined

Timbre is digitally printed. Batch to batch variation can occur.

## PANEL



0.35" Panel Size: 48 <sup>1</sup>/<sub>16</sub>" x 96 <sup>1</sup>/<sub>16</sub>" (1220 x 2440mm)  
Print Size: 47 <sup>1</sup>/<sub>4</sub>" x 94 <sup>1</sup>/<sub>2</sub>" (1200mm x 2400mm min.)

0.47" Panel Size: 48 <sup>1</sup>/<sub>16</sub>" x 110 <sup>1</sup>/<sub>4</sub>" (1220mm x 2800mm)  
Print Size: 47 <sup>1</sup>/<sub>4</sub>" x 106 <sup>5</sup>/<sub>16</sub>" (1200 x 2700mm min.)

0.94" Panel Size: 49 <sup>3</sup>/<sub>16</sub>" x 108 <sup>1</sup>/<sub>4</sub>" (1250mm x 2750mm)  
Print Size: 47 <sup>1</sup>/<sub>4</sub>" x 106 <sup>5</sup>/<sub>16</sub>" (1200mm x 2700mm min.)

----- Trimming Line