Design Studio Tiles Peel + Stick Instructions





design studio

Hear yourself think®

Design Studio Tiles - Peel + Stick Instructions

1. Peel the backer from the tile.

2. Lightly spray the adhesive side of the tile with mild soapy water ensuring that there are no dry spots.

3. Place the tile in its approximate location.

4. While the adhesive is wet with the soapy water, the tile can be maneuvered into alignment. When the tile is in its desired location, press firmly against the wall to set it in place. Please allow 24 hours for the tile to thoroughly dry for a permanent bond.



