

DIGITALLY PRINTED PRODUCT CARE



unika vaev


Hear yourself think®

Digitally Printed Products


The products seen below are all able to be finished with Unika Vaev's state-of-the-art digital printing.



8 Squared



Acoustic LED Ceiling Tiles - Lineal



Acoustic LED Ceiling Tiles - Spot



Acoustic Panel Prints



Arbor Alto




Artisan Acoustic Wallcovering



Beam



Coffered Ceiling Tile Collection



Ecooustic® Ceiling Flats



Light Beam



Light Blade Baffle



Louver Tiles




Madera Plank




Measure Baffles



Octave Baffles



Pinnacle



Radius Panel

Digitally Printed Product Care

To clean the printed surface, you'll want to be gentle to avoid damaging the print. Here are a few steps you can follow:

1. Start by removing any loose dirt or debris from the surface of the material. You can use a soft brush or a lint-free cloth to gently brush away the particles.
2. Dampen a soft cloth with mild soap or detergent diluted in water. Ensure that the soap or detergent is suitable for delicate materials. Avoid using harsh chemicals or abrasive cleaners, as they can damage the print.
3. Gently blot the printed surface of the material using a damp cloth. If blotting does not remove the full stain, gently wipe the stain. Be careful not to scrub too vigorously or apply excessive pressure, as this may cause the print to fade or smudge.
4. If there are any stubborn stains or marks, you can try using a mild solution of isopropyl alcohol or rubbing alcohol. Apply a small amount to a clean cloth and gently blot the stained area. Test the alcohol on a small, inconspicuous area first to ensure it doesn't affect the print.
5. After cleaning, rinse the cloth thoroughly and wring out any excess moisture. Then, dampen the cloth with clean water and blot or wipe the surface again to remove any soap residue or cleaning solution.
6. Finally, allow the material to air dry completely before handling or using it again.